



Hanging Instructions For Maya Romanoff Studio

CHECK LIST

- Check wallcoverings are as ordered and as specified. Identification samples are available from MURASPEC immediately.
- Check wallcoverings are free from damage caused by transit.
- Check that there is enough of each material and batch before cutting. Never use material from different batches on one wall.
- Check each new roll matches material already hung for acceptable colour match.
- Use only MURABOND products in strict accordance with pack instructions.
- Ensure good lighting, which is required for proper inspection before, during and after hanging and that the site is heated to at least 12°C [55°F], and that ventilation is good during hanging and drying.
- Always carry out a trial hang of three drops. Leave for one hour, then inspect. Stand back after each drop and assess the results.
- STOP IF YOU THINK THE RESULT MAY NOT BE ACCEPTABLE.** No claims can be accepted for more than three drops once material has been cut. Keep all labels until after the job has been accepted.

GENERAL PREPARATION

1. Brush off all dirt and loose material with a stiff bristle brush.
2. All surface contaminations such as dirt, grease, polish, water soluble stains, felt tip pen marks, etc., should be removed by washing with a detergent solution, rinsed off with clean water and allowed to dry.
3. Mould and Algae should be treated with a fungicidal wash and use in accordance with the pack instructions and allow to dry.
4. Any holes, cracks or defects to be filled flush with a good quality filler, used in strict accordance with the manufacturer's instructions.
5. All substrates should be dry in depth.

UNCOATED ABSORBENT SURFACES

- Apply one coat of Murabond Primer diluted 1 part to 3 part clean water. Allow to dry.

COATED ABSORBENT SURFACES

- PLEASE NOTE: Multi-coats may impair the porosity of the surface and affect adhesion. If in doubt or if an oil-based paint forms part of the system, then contact Muraspec for advice.
- Ensure all substrates are dry in depth. Apply a coat of Murabond Primer diluted 1 part to 1 part clean water. Allow to dry.

Then hang the wallcovering using the following method: -

Adhesive:	Murabond Heavy Adhesive.
Applied to:	Paste the wall surface.
Direction of Hang:	See Page 2.
Type of Joint:	Overlap to Match Pattern If Required & Trim Through.
Pattern Match:	See Page 2.

FOR NON-ABSORBENT SURFACES

- PLEASE NOTE: If the surface is cement or concrete or is unstable in anyway, seek further advice.
- Any filled, patched or absorbent areas should be equalised in colour and absorbency with a similar pigmented oil-based paint.

Then hang the wallcovering using the following method: -

Adhesive:	Murabond Sealed Surface Adhesive.
Applied to:	Paste the wall surface.
Direction of Hang:	See Page 2.
Type of Joint:	Overlap to Match Pattern & Trim Through.
Pattern Match:	See Page 2.

Murabond Adhesive should be applied one drop at a time to keep within the open time of the adhesive. When hanging on uncoated Plasterboard, use Murabond Easy Strip Adhesive.