

EVERGLADES WALLCOVERING HANGING INSTRUCTIONS

Thank you for choosing one of our Everglades Grasscloth wallcoverings. For the best results we would recommend a professional installer should hang this product.

Before hanging this wallcovering, all rolls should be examined for the correct pattern, product code ordered and that there is enough material to complete the project. It is important that you work in good natural light and that the temperature/environmental conditions are stable.

Preparation:

- If your wall has existing wallcovering, you will need to remove it. Any painted surfaces should be sanded and thoroughly washed down. If the painted wall is a dark colour we recommend that you repaint it with a good quality, water-based, white primer.
- Repair any cracks or holes with an oil free filling, and sand.
- The wall surface should be flat, solid, free from dust, dirt, grease and have a non-alkali finish.
- Any newly sealed wall surface should be allowed to fully dry prior to installation.

Hanging:

- Make sure you use a brand new cutting knife/blade when installing this product and change blades regularly as it is a natural product. Take care around fixtures such as sockets.
- Use a heavy-duty clear adhesive that has not been diluted. We would suggest our Murabond Heavy adhesive.
- Cut the lengths to size allowing extra for trimming at ceiling and skirting. Arrange the lengths in sequence and number the back of each length with a pencil. **Do not reverse: hang all drops the same way.**
- Everglades may be difficult to turn around corners. We recommend that it should not be turned but trimmed flush and the subsequent drop hung working away from the corner.
- Using a brush or roller, paste the adhesive directly onto the wall.
- Hang the first length using a plumb line.
- Using a rounded plastic wallcovering applicator, smooth down the centre of the paper to push out the air. Next, smooth downward at an angle towards the outer edges from either side of the centre. Do not allow the adhesive onto the face of the wallcovering as it may be impossible to remove and will affect the finished look of this product.
- **Follow in sequence the next drops, butt joining only.** Smooth together and press down on the edges.
- Once the paper is all hung, trim at ceiling and skirting level using a sharp blade.

Remember!! If you encounter any problems during installation, i.e., excessive shading or defects in the construction of the material, **do not hang/Cut more than three drops** before contacting Muraspec or Fardis wallcoverings customer Services.

Product Removal Guides:

In the future you may wish to remove this wallcovering to replace with a new option. We recommend that you fully protect your environment with appropriate covers and sheeting, especially on carpets/flooring and soft furnishings.